



Toshiba Satellite P755 S5390 Touchpad Repair

Repair a disconnected touchpad on your Toshiba Satellite laptop.

Written By: Dominic Oldani



INTRODUCTION

A broken touchpad is annoying on any laptop. Sometimes this is an easy fix. Use this guide to fix a disconnected touchpad on your Toshiba Satellite P755 S5390.



TOOLS:


- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Toshiba Satellite P755 S5390 Touchpad Repair




- i** Make sure that your laptop is powered off before continuing.
- Close the laptop lid and turn it over so that the spine is facing away from you.
 - Slide the left slider, which is to the left the battery compartment, into its leftmost position.

Step 2



- Slide and hold the right slider into its rightmost position.
- Lift the battery out of the compartment.

Step 3




- Remove fifteen Phillips #1 screws from the back of the laptop.

Step 4



- Turn the laptop back over and open the lid.


Step 5



- Gently pry up the keyboard.
- Continue to pry off the rest of the keyboard.




⚠ Don't touch the motherboard.

Step 6



- Check if the touch pad cable is plugged into the ZIF connector on the motherboard.

Step 7



- Grab the blue plastic above the touch pad wire.
- While holding the blue plastic piece, firmly plug the cable into its socket on the motherboard.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-16 07:52:14 PM.